


STC8H2K08U-STC8H1K08T触摸演示V1.0-B

2024-01-16
www.STCAL.com



出厂不焊 U4。如焊 U4, 必须去掉 R35

