

DSB
(Charge)

Exp
100

Charging reminder

Power
ON ← OFF



AC
↕
DC

IN

Digital oscilloscope

Sampling rate: 500kHz
Analog bandwidth: 100kHz
Trigger mode:
Auto/Standard/Single

A control panel with six circular buttons. From left to right: a button labeled 'T', a button labeled 'T2', a button labeled 'M', a button labeled 'N', a button labeled 'S/S', and a button labeled 'OK'. The buttons are arranged in two rows of three.

1000Hz
OCT
100Hz